



PROTOCOL Blocked Drain

Purpose

To describe the activities required to clear a drain back-up without cross-contamination to production areas

Equipment

Black plastic bag
Black scrapers
Black buckets
Black grip squeegee

PPE

Safety Shoes
Rubber Gloves
Black dustcoat

Product

Shureclean	1:100
Delladet sanitizer	1:100 ready to use in spray bottle

Instructions

- Notify a quality representative in the area
- If production is in operation, the affected area should be shut down immediately
- Isolate the area with danger tape and avoid any unnecessary through traffic
- Remove all pallets, supplies and ingredients from the area and assess for water contamination
- Reject any exposed product
- Correct the issue, ensuring that any equipment brought into the production area by the plumbing contractor is hygienically clean
- Discard any drain waste into a refuge bag
- Clean and sanitize the floor and any surface that came into contact with the drain material. This is to include the shoes of people involved
- Production may resume once the area has been inspected by a quality representative
- Clean and sanitize the cleaning equipment and store in a secure area apart from normal production cleaning equipment

