

PROTOCOL Blocked Toilet

Purpose

To describe the activities involved in clearing a toilet back-up, whilst preventing cross-contamination to the rest of the site

Equipment

Red chequered cloth
Red plastic scrapers
Red buckets
Red grip squeegee

PPE

Safety Shoes
Rubber Gloves
Red Dustcoat

Product

Shureclean	1:100
Delladet sanitizer	1:100 ready to use in spray bottle

Instructions

- The bathroom must be temporarily shut down, by either locking, making use of danger tape or erecting signs
- Remove any items that may have been affected
- Correct the issue
- Discard any waste into a refuse bag
- Clean and sanitise the toilet bowl and any surfaces that were in contact with the back-up, according to work instructions – check that under the rim of the toilet bowl is clean
- Clean and sanitise the floor according to work instructions – ensure the floor is dry
- The mop/squeegee head and water must be discarded
- Clean and sanitise the bucket used
- Open the bathroom for use
- Document the incident (job card)

